



Survey and Contamination Monitoring

■ Dose Rate Monitors



Dose rate meter
Minitrace γ



High dose rate probe
SHF

■ Contamination Monitors



Contamination meter
Minitrace β



α and β low background counter
PAB-2



α and β floor contamination monitor
CW 28-N